

# SHRUB PLANTING DETAIL

Remove any container or twine and burlap.

Backfill using existing soil. Water thoroughly to eliminate air pockets.

Add 1-2 inches of hardwood mulch. Keep mulch 3 inches from trunk.

Remove tags and labels.

Prune only dead or broken branches or double leaders.

Remove excess soil to locate and expose root flare.

Root flare should be 1-2 inches above finish grade.

Finish grade.

LEAVE SOIL UNDER ROOT BALL UNDISTURBED TO HELP SUPPORT IT AND REDUCE SETTLING.

1 1/2 - 2 TIMES BALL DIAMETER

